


CFD-460

SERVICE MANUAL

US Model
Canadian Model



SPECIFICATIONS

AUDIO POWER SPECIFICATIONS

With 3.2-ohm loads, both channels driven from 150–10,000 Hz: rated 4 W, per channel minimum RMS power, with no more than 10% total harmonic distortion in AC operation.

OTHER SPECIFICATIONS

CD player section

System	Compact disc digital audio system
Laser diode properties	Material: GaAlAs Wavelength: 780 nm Emission duration: Continuous Laser output power: less than 44.6 μ W* *This output is the value measured at a distance of 200 mm from the objective lens surface on the optical pick-up block.
Spindle speed	12 cm CD: Approx. 200 to 500 r.p.m. (CLV) 8 cm CD: Approx. 300 to 500 r.p.m. (CLV)
Error correction	Sony Super Strategy Cross Interleave Reed Solomon Code
Number of channels	2
Frequency response	20–20,000 Hz: $\pm 1/2$ dB
Wow and flutter	Below measurable limit

Radio section

Frequency range	FM: 87.6–108 MHz AM: 530–1,710 kHz
Antennas	FM: Telescopic antenna AM: Built-in ferrite bar antenna

Tape recorder section and general

Recording system	4-track 2-channel stereo
Fast winding time	Approx. 2 min. with Sony cassette C60
Frequency response	With TYPE I (NORMAL) cassette: 80–10,000 Hz

Model Name Using Similar Mechanism	CD Section	CFD-454/455
	Tape Section	CFS-W304
Optical Device Name		KSM-150BG
Tape Transport Mechanism Type		MF-460-64

Speakers	Woofer: 12 cm dia., cone type Tweeter: 2 cm dia.
Power output	Model for Canada: 4.3 W + 4.3 W (at 3.2 ohms, 315 Hz, 10% harmonic distortion)
Inputs	External microphone input jack (minijack) Sensitivity 0.78 mV For low impedance microphone
Outputs	Headphones jack (stereo minijack) For 16–68 ohms impedance headphones
Power requirements	120V AC, 60 Hz DC 12V, 8 size D (R20) batteries
Power consumption	AC 21W (for US model) AC 25W (for Canadian model)

Battery life

Batteries	Sony SUM-1 (NS)	Sony Alkaline AM1
FM recording	Approx. 15 hrs	Approx. 35 hrs
Disc playing	Approx. 6 hrs	Approx. 16 hrs

Dimensions	677 × 292 × 194 mm (w/h/d) (26 3/4 × 11 1/2 × 7 3/4 inches) incl. projecting parts and controls
Weight	7.7 kg (16 lb 15 oz) incl. batteries
Accessory supplied	AC power cord (1)

Design and specifications subject to change without notice.

CD RADIO CASSETTE-CORDER
SONY®

TABLE OF CONTENTS

<u>Section</u>	<u>Title</u>	<u>Page</u>
1. GENERAL		
	Parts Identification	4
2. DISASSEMBLY		
2-1.	Front Cabinet Assy	5
2-2.	Handle	5
2-3.	Pointer Setting	5
3. MECHANICAL ADJUSTMENTS		6
4. ELECTRICAL ADJUSTMENTS		
4-1.	Tape Recorder Section	6
4-2.	Radio Section	7
4-3.	CD Section	9
5. DIAGRAMS		
5-1.	Circuit Boards Location	13
5-2.	Semiconductor Lead Layout.....	14
5-3.	Block Diagram	15
5-4.	Printed Wiring Board—Tuner, Audio Section—	18
5-5.	Schematic Diagram —Tuner Section—.....	21
5-6.	Schematic Diagram —Audio Section—.....	23
5-7.	Schematic Diagram —CD Section—	28
5-8.	Printed Wiring Board —CD Section—	31
6. EXPLODED VIEWS		
6-1.	Front Cabinet Assembly	34
6-2.	Rear Cabinet Assembly	35
6-3.	CD Unit Assembly	36
6-4.	Optical Block	37
6-5.	Mechanism Block (1) (Deck A)	38
6-6.	Mechanism Block (2) (Deck A)	39
6-7.	Mechanism Block (3) (Deck B)	40
6-8.	Mechanism Block (4) (Deck B)	41
6-9.	Pspeaker Assembly	42
7. ELECTRICAL PARTS LIST		43

SAFETY-RELATED COMPONENT WARNING!!

COMPONENTS IDENTIFIED BY MARK  OR DOTTED LINE WITH MARK  ON THE SCHEMATIC DIAGRAMS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY.

SAFETY CHECK-OUT

After correcting the original service problem, perform the following safety check before releasing the set to the customer:

Check the antenna terminals, metal trim, “metallized” knobs, screws, and all other exposed metal parts for AC leakage. Check leakage as described below.

LEAKAGE TEST

The AC leakage from any exposed metal part to earth ground and from all exposed metal parts to any exposed metal part having a return to chassis, must not exceed 0.5 mA (500 microamperes). Leakage current can be measured by any one of three methods.

1. A commercial leakage tester, such as the Simpson 229 or RCA WT-540A. Follow the manufacturers' instructions to use these instruments.
2. A battery-operated AC milliammeter. The Data Precision 245 digital multimeter is suitable for this job.
3. Measuring the voltage drop across a resistor by means of a VOM or battery-operated AC voltmeter. The “limit” indication is 0.75 V, so analog meters must have an accurate low-voltage scale. The Simpson 250 and Sanwa SH-63Trd are examples of a passive VOM that is suitable. Nearly all battery operated digital multimeters that have a 2 V AC range are suitable. (See Fig. A)




Fig. A. Using an AC voltmeter to check AC leakage.

ATTENTION AU COMPOSANT AYANT RAPPORT À LA SÉCURITÉ!

LES COMPOSANTS IDENTIFIÉS PAR UNE MARQUE  SUR LES DIAGRAMMES SCHÉMATIQUES ET LA LISTE DES PIÈCES SONT CRITIQUES POUR LA SÉCURITÉ DE FONCTIONNEMENT. NE REMPLACER CES COMPOSANTS QUE PAR DES PIÈCES SONY DONT LES NUMÉROS SONT DONNÉS DANS CE MANUEL OU DANS LES SUPPLÉMENTS PUBLIÉS PAR SONY.

SERVICING NOTES

NOTES ON HANDLING THE OPTICAL PICK-UP BLOCK OR BASE UNIT

The laser diode in the optical pick-up block may suffer electrostatic breakdown because of the potential difference generated by the charged electrostatic load, etc. on clothing and the human body.

During repair, pay attention to electrostatic breakdown and also use the procedure in the printed matter which is included in the repair parts.


The flexible board is easily damaged and should be handled with care.

NOTES ON LASER DIODE EMISSION CHECK

The laser beam on this model is concentrated so as to be focused on the disc reflective surface by the objective lens in the optical pick-up block. Therefore, when checking the laser diode emission, observe more than 25 cm away from the objective lens.

LASER DIODE AND FOCUS SEARCH OPERATION CHECK


1. Turn POWER switch on with no disc inserted and make Function switch to CD position.
2. Open the lid for CD.
3. Turn on S801 as following figure.
4. Press ► key.
5. Confirm the laser diode emission while observing the objecting lens. When there is no emission, Auto Power Control circuit or Optical Pick-up is broken.
Objective lens moves up and down three times for the focus search.



CHUCK PLATE JIG ON REPAIRING

On repairing CD section, playing a disc without the CD lid, use Chuck Plate Jig.

- Code number of Chuck Plate Jig: X-4918-255-1




NOTE ON REPAIRING

The spindle motor (M702) and the turntable assembly are individually supplied as repair parts.


When repairing M702, please order the turntable assembly together.

Dimension is as follows.




Parts Identification

General



- 1 PHONES (headphones) jack (stereo minijack)
- 2 OPR/BAT (operation/battery) indicator
- 3 BALANCE control
- 4 BASS BOOST control (for listening only)
- 5 GRAPHIC EQUALIZER controls (for listening only)
- 6 FUNCTION selector
CD: For listening to/recording CD sound.
RADIO: For listening to/recording radio programs.
DUBBING: For tape dubbing.
TAPE (CD RADIO OFF): For listening to tapes. (For turning off the CD player or the radio.)
- 7 FM ST (FM stereo) indicator
- 8 BAND selector
FM: For listening to/recording FM radio programs.
AM: For listening to/recording AM radio programs.
- 9 VOLUME control
- 10 Tweeter
- 11 Woofer

CD player section




- 12 Display window
- 13 Disc cover
- 14 PLAY MODE button
INTRO: To scan all the selections
REPEAT 1: To repeat one of the selections
REPEAT ALL: To repeat all the selections
REPEAT SHUFFLE: To play the selections repeatedly in a random order.
REPEAT PGM: To play the selections repeatedly in the desired order.
PGM: To play the selections in the desired order.
- 15 REMAIN/ENTER button
- 16 PUSH OPEN/CLOSE button
- 17 << >> AMS/SEARCH buttons
- 18 > PLAY button
- 19 || PAUSE button
- 20 ■ STOP button

CD display window


- 21 Pause/play indication
- 22 Play mode indication
- 23 MEM (memory) indication
- 24 TRACK indication
- 25 MIN (minute) indication
- 26 SEC (second) indication

Tuner section



- 27 Dial scale and pointer
- 28 TUNING control

Tape recorder section



- 29 Cassette holders


(Deck A)

- 30 ■▲ (stop/eject) button
- 31 HI (high) SPEED DUBBING button
- 32 > (play) button
- 33 << (rewind) button
- 34 >> (fast forward) button
- 35 || (pause) button

(Deck B)

- 36 ■▲ (stop/eject) button
- 37 ● (record) button
- 38 > (play) button
- 39 << (rewind) button
- 40 >> (fast forward) button
- 41 || (pause) button

Rear panel



- 42 Telescopic antenna
- 43 AC IN (AC power input) socket
- 44 Speaker cord
- 45 MIX MIC (mixing microphone) jack (minijack)
- 46 Battery compartment (bottom)
- 47 SPEAKER terminals
- 48 ISS (interference suppress switch)


SECTION 1 GENERAL

This section is extracted from instruction manual.


SECTION 2 DISASSEMBLY

Note : Follow the disassembly procedure in the numerical order given.


2-1. FRONT CABINET ASSY



2-2. HANDLE



2-3. POINTER SETTING



SECTION 3 MECHANICAL ADJUSTMENTS

PRECAUTION

- Clean the following parts with a denatured-alcohol-moistened swab :

record/playback head	pinch roller
erase head	rubber belts
capstan	idlers
- Demagnetize the record/playback head with a head demagnetizer. (Do not bring the head demagnetizer close to the erase head.)
- Do not use a magnetized screwdriver for the adjustments.
- After the adjustments, apply suitable locking compound to the parts adjusted.
- The adjustments should be performed with the rated power supply voltage unless otherwise noted.
- Power supply voltage : 12V dc.

Torque Measurement

Torque	Torque meter	Meter reading
Forward	CQ-102C	20—60g·cm (0.28—0.83 oz·inch)
Forward back tension	CQ-102C	2—6g·cm (0.028—0.083 oz·inch)
Reverse	CQ-102RC	20—60g·cm (0.28—0.83 oz·inch)
Reverse back tension	CQ-102RC	2—6g·cm (0.028—0.083 oz·inch)
Fast Forward	CQ-201B	more than 45g·cm (more than 0.62 oz·inch)
Rewind	CQ-201B	more than 45g·cm (more than 0.62 oz·inch)

Tape Tension Measurement

Mode	Meter	Meter Reading
Forward	CQ-403A	more than 70g (more than 2.47 oz)
Reverse	CQ-403R	

SECTION 4 ELECTRICAL ADJUSTMENTS

4-1. TAPE RECORDER SECTION

Standard Input Level

	MIC IN
Source impedance	300 Ω
input level	2.451 mV (—50dB)

Standard Output Level

Output terminal	SP OUT	PHONES OUT
load impedance	3.2 Ω	32 Ω
output signal level	0.775V (0dB)	0.25V (—10dB)

Test Tape


Type	Signal	Used for
WS-48A	3kHz, 0dB	tape speed adjustment

Tape Speed Adjustment **DECK A** **DECK B**

Procedure :

- Perform high speed adjustment before normal speed adjustment.


Mode : playback



Speed	S402 (CNP312)	Deck	Adjustment point	Frequency counter
High	ON	A	RV304	5,980—6,020Hz
		B	confirm	
Normal	OFF	A	RV303	2,990—3,010Hz
		B	confirm	

Frequency difference between the beginning and the end of the tape should be within $\pm 0.35\%$.

Adjustment Location :




4-2. RADIO SECTION

• FM Section

Setting :

BAND switch : FM




22.5kHz frequency
deviation by 400Hz signal
output level : as low as possible


• AM Section

Setting :

BAND switch : AM



30% amplitude
modulation by
400Hz signal



- Repeat the procedures in each adjustment several times, and the frequency coverage and tracking adjustments should be finally done by the trimmer capacitors.

FM FREQUENCY COVERAGE ADJUSTMENT	
Adjust for a maximum reading on VTVM.	
L2	CT2
86.5MHz	109.5MHz

FM TRACKING ADJUSTMENT	
Adjust for a maximum reading on VTVM.	
L1	CT1
86.5MHz	109.5MHz


AM FREQUENCY COVERAGE ADJUSTMENT	
Adjust for a maximum reading on VTVM.	
T1	CT4
516kHz	1,760kHz

AM TRACKING ADJUSTMENT	
Adjust for a maximum reading on VTVM.	
L3	CT3
620kHz	1,400kHz

AM IF ADJUSTMENT	
Adjust for a maximum reading on VTVM.	
CP1	
455kHz	

Adjustment Location : Audio Main board

AUDIO MAIN BOARD —Component side—



4-3. CD SECTION

Notes on Adjustment

1. Perform adjustment in service mode.
After adjustment, be sure to release service mode.
2. Perform adjustments in the order given.
3. Use the disc (YEDS-18, Part No. 3-702-101-01) only when so indicated.

Before Adjustment

Put the set into service mode and perform the following checks. Repair if there are any problems.

• Sled Motor Check


1. Press ► key, then press ■ key.
2. Press ►►, ◀◀ keys and confirm that the FOP moves smoothly from the innermost to outermost circumference and back smoothly and with no catching or abnormal noises.
►►: FOP moves to the outer circumference
◀◀: FOP moves to the inner circumference

• Focus Search Check


1. Press ► key. (Focus search operation is performed continuously.)
2. Look at the FOP objective lens and confirm that it moves up and down smoothly, with no catching or abnormal noises.
3. Press' ■ key.
Confirm that focus search operation stops. If it does not, press ■ key again longer.

How to Put the Set into Service Mode

1. Solder-bridge the following portion on the CD main board.
2. Turn the power on.




VCO Adjustment



Adjustment Procedure :

1. Make a solder bridge at portion ① on CD main board.
2. Adjust RV703 so that the reading on the frequency counter becomes 4.3218MHz.
3. Remove the solder-bridge at ① portion.




- See page 12 for Adjustment Location.


Traverse Adjustment

This adjustment is to be done when the optical block is replaced.


Adjustment Procedure :



1. Connect the oscilloscope between TP (TE) and TP (VREF).
2. Put the set into service mode.
3. Press the ►► and ◀◀ keys to move the FOP to the center.
4. Insert disc (YEDS-18) and press ► key.
5. Adjust RV701 so that the oscilloscope traverse waveform is symmetrical, as shown in the figure below.
6. Release service mode after adjustment is completed.




Adjustment value : $2 \pm 0.5V_{p-p}$



Focus Bias Adjustment


This adjustment is to be done when the optical block is replaced.

Adjustment Procedure :



1. Connect the oscilloscope between TP (RF) and TP (VREF).
 2. Put the set into service mode.
 3. Press the ►► and ◀◀ keys to move the FOP to the center. (Move the FOP to the music area on the disc to enable easy visibility of the eye pattern.)
 4. Insert disc (YEDS-18) and press ► key.
 5. Adjust RV702 so that the oscilloscope waveform is as shown in the figure below (eye pattern).
- A good eye pattern means that the diamond shape (◊) in the center of the waveform can be clearly distinguished.
6. Release service mode after adjustment is completed.

• RF signal reference waveform (eye pattern).



When observing the eye pattern, set the oscilloscope for AC range and raise vertical sensitivity.

• See page 12 for Adjustment Location.

REFERENCE

Focus/Tracking Gain Adjustment

A frequency response analyzer is necessary in order to perform this adjustment exactly.

However, this gain has a margin, so even if it is slightly off, there is no problem. Therefore, do not perform this adjustment.

Focus/tracking gain determines the pick-up follow-up (vertical and horizontal) relative to mechanical noise and mechanical shock when the 2-axis device operate.

However, as these reciprocate, the adjustment is at the point where both are satisfied.

- When gain is raised, the noise when the 2-axis device operates increases.
- When gain is lowered, it is more susceptible to mechanical shock and skipping occurs more easily.
- When gain adjustment is off, the symptoms below appear.


	Gain	Focus	Tracking
Symptoms			
• The time until music starts becomes longer for STOP →▶ PLAY on automatic selection (◀◀, ▶▶ buttons pressed. (Normally takes about 2 seconds.)	low	low	low or high
• Music does not start and disc continues to rotate for STOP →▶ PLAY or automatic selection (◀◀, ▶▶ buttons pressed.)	—	—	low
• Sound is interrupted during PLAY. Or time counter display stops progressing	—	—	low
• More poise during 2-axis device operation.	high	high	high

The following is a simple adjustment method.


—Simple Adjustment—

Note : Since exact adjustment cannot be performed, remember the positions of the controls before performing the adjustment. If the positions after the simple adjustment are only a little different, return the controls to the original position.



Procedurd :




1. Keep the set horizontal.
If the set not horizontal, this adjustment cannot be performed due to the gravity against the 2 axis device.
2. Insert disc (YEDS-18) and press ▶ PLAY button.
3. Connect oscilloscope to CD main board TP (FOK).
4. Adjustment RV705 so that the waveform is as shown in the figure below. (focus gain adjustment)



- Inccorrent Examples (DC level changes more than on adjusted waveform)




5. Connect oscilloscope to TP (TE).
6. Adjust RV704 so that the waveform is as shown in the figure below. (Tracking gain adjustment)




• Incorrect Examples (fundamental wave appears)

low tracking gain






high tracking gain
(higher fundamental wave than for low gain)



Adjustment Location :

CD MAIN BOARD

—Component side—




*
Remove the solder bridge
while adjustment of focus
gain.
(After adjustment make the
solder bridge)

*
Remove the solder bridge
while adjustment of tracking
gain.
(After adjustment make the
solder bridge)

* Note : When a frequency response
analyzer is used :


SECTION 5 DIAGRAMS

5-1. CIRCUIT BOARDS LOCATION




5-2. SEMICONDUCTOR LEAD LAYOUT

BA6294



MARKING SIDE VIEW

CXD1130Q




MARKING SIDE VIEW

PST5290D




Pin 1 Vcc
2 OUTPUT
3 GND


2SD1815-K



2SD1944-K




CXA1081Q




MARKING SIDE VIEW

CXP5024-092Q




(TOP VIEW)

TA8189N




(TOP VIEW)

CXA1182Q-Z




CXA1238S




(TOP VIEW)

CXA1352S




(TOP VIEW)

LA4597




(TOP VIEW)

LH5116AN-10




(TOP VIEW)

**MC4558-C
NJM2100D**



(TOP VIEW)

μPD6376GS




(TOP VIEW)


**KSC1008-R
KSR1003
KSR1006
KSR1008
KSR1009
KSR2003
2SB1013-4**




2SC2785-HFE




2SK105A-30




**MTZN-10B
RD6.2ES-B2
RD6.8ES-B2
1SS119**



SEL2210R-D




5-3. BLOCK DIAGRAM




5-4. PRINTED WIRING BOARD —TUNER, AUDIO Section— • Refer to page 14 for Semiconductor Lead Layouts.

• Semiconductor Location

Ref. No.	Location
D1	E-16
D2	E-16
D3	H-13
D301	G-13
D302	G-12
D303	G-12
D304	E-8
D305	E-8
D306	H-6
D307	C-9
D308	C-9
D309	C-10
D310	E-9
D311	F-12
D312	F-8
D313	E-8
D901	E-3
IC1	E-15
IC301	D-11
IC302	F-9
IC303	F-7
Q5	G-13
Q6	G-12
Q102	F-11
Q202	F-11
Q301	B-13
Q302	E-10
Q303	E-8
Q304	F-8
Q305	F-8
Q306	C-10
Q308	B-11
Q309	C-9
Q311	B-11
Q313	C-9
Q314	I-18
Q315	I-17
Q316	I-17
Q317	I-17
Q319	C-7
Q320	E-10
Q321	B-14
Q322	B-14
Q323	C-10




5-5. SCHEMATIC DIAGRAM —TUNER Section—




- Note:**
- All capacitors are in μF unless otherwise noted. pF : μF 50WV or less are not indicated except for electrolytics and tantalums.
 - All resistors are in Ω and $\frac{1}{4}\text{W}$ or less unless otherwise specified.
 - --- : B+ Line
 - --- : adjustment for repair.
 - Power voltage is dc12V and fed with regulated dc power supply from battery terminal.
 - Voltage and waveforms are dc with respect to ground under no-signal (detuned) conditions.
no mark: FM
() : AM
 - Voltages are taken with a VOM (Input Impedance $10\text{M}\Omega$). Voltage variations may be noted due to normal production tolerances.
 - **Signal path.**
 $\Rightarrow$: FM


• IC Block Diagram —Tuner Section—




1
TO AUDIO
MAIN BOARD
(2/2)
(See page 23.)




IC301 TA8189

[illegible]


IC701 CXA1081Q



IC703 CXD1130Q




IC708,709 BA6294



1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P



Note:

- All capacitors are in μF unless otherwise noted. pF : μF 50WV or less are not indicated except for electrolytics and tantalums.
- All resistors are in Ω and $\frac{1}{2}\text{W}$ or less unless otherwise specified.
- : fusible resistor.

Note:

The components identified by mark or dotted line with mark are critical for safety. Replace only with part number specified.

Note:

Les composants identifiés par une marque ou une ligne pointillée avec la marque sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

• : B+ Line

• : adjustment for repair.

• Power voltage is dc12V and fed with regulated dc power supply from battery terminal.

• Voltage and waveforms are dc with respect to ground under no-signal conditions.

• Voltages are taken with a VOM (Input Impedance 10M Ω). Voltage variations may be noted due to normal production tolerances.

• Waveforms are taken with an oscilloscope. Voltage variations may be noted due to normal production tolerances.


• Signal path.

• : CD


5-8. PRINTED WIRING BOARD —CD Section— • Refer to page 14 for Semiconductor Lead Layouts.

• Semiconductor Location



Ref. No.	Location
D701	B-5
D702	B-5
D801	C-6
D802	C-6
D804	G-3
D805	F-3
IC701	F-7
IC702	F-5
IC703	D-6
IC704	D-7
IC706	C-4
IC707	D-5
IC708	E-3
IC709	E-3
IC801	B-7
IC802	G-3
IC803	F-13
IC804	A-6
Q701	F-7
Q702	D-3
Q703	D-3
Q704	B-6
Q705	D-3
Q706	D-3
Q711	A-5
Q712	C-3
Q713	C-3
Q714	D-4
Q791	F-6
Q792	F-7
Q801	A-6
Q802	B-6
Q803	D-8



LCD 1



IC702 CXA1182Q-Z

IC707 μ PD6376GS

Note:

- — : parts extracted from the component side.
- — : Jumper wire connected to the ground pattern on the component side.

SECTION 6 EXPLODED VIEWS

NOTE:

- The mechanical parts with no reference number in the exploded views are not supplied.
- The construction parts of an assembled part are indicated with a collation number in the remark column.
- Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

- Due to standardization, parts with part number suffix -XX and -X may be different from the parts specified in the components used on the set.

- Color Indication of Appearance Parts
Example:

KNOB, BALANCE (WHITE) ... (RED)


↑ ↑
Parts' Color Cabinet's Color

- Screw (# mark) list is given in the last of this parts list.

The components identified by mark or dotted line with mark are critical for safety. Replace only with part number specified.


Les composants identifiés par une marque sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

6-1. FRONT CABINET ASSEMBLY



Ref.No	Part No.	Description	Remarks	Ref.No	Part No.	Description	Remarks
1	X-3362-578-1	HOLDER SUB (A) ASSY, CASSETTE		19	4-930-277-01	SCREW (4.5X8),TAPPING,PAN HEAD	
2	X-3362-579-1	HOLDER SUB (B) ASSY, CASSETTE		20	*4-930-230-01	GUIDE, POINTER	
3	4-930-233-01	SPRING		21	3-365-839-01	RETAINER (B)	
4	*4-930-280-01	GUIDE (C)		22	3-365-838-01	RETAINER (A)	
5	4-920-985-01	SPRING (H)		23	3-365-852-01	RETAINER (VC)	
6	3-343-248-01	DAMPER (P), SMALL		24	*1-638-104-11	PC BOARD, GEQ VOL	
7	4-930-231-01	FOOT		25	*1-638-105-11	PC BOARD, TC	
8	4-920-976-01	KNOB (VOLUME)		26	*A-3261-419-A	AUDIO MAIN BOARD, COMPLETE	
9	4-920-975-01	KNOB (TUNING)		27	*4-920-997-01	GEAR, V.C.	
10	4-920-993-01	JOINT (B)		28	3-365-836-01	ARM, REC	
11	X-3362-580-1	BUTTON (A) BLOCK ASSY, MD		29	X-3362-582-1	CABINET SUB ASSY, FRONT	
12	X-3362-581-1	BUTTON (B) BLOCK ASSY, MD		30	3-366-933-01	PLATE ORNAMENTAL	
13	4-930-209-01	RACK, POINTER		31	3-367-706-01	KNOB, BAND SELECT	
14	4-930-283-01	SPRING, COMPRESSION		32	3-831-441-XX	CUSHION, CABINET, UPPER 10X7X0.3	
15	4-930-282-01	WASHER (T), POLY-SLIDER		S304	1-571-330-21	SWITCH, LEAF (MD (A) POWER)	
16	4-920-977-01	GEAR, CONVERSION		S305	1-571-890-11	SWITCH, LEAF (REC PROOF)	
17	4-934-505-01	GEAR, IDLER		S306	1-571-330-21	SWITCH, LEAF (MD (B) POWER)	
18	4-920-979-01	SPRING		S307	1-571-890-11	SWITCH, LEAF (120μ/70μ)	

6-2. REAR CABINET ASSEMBLY




Note:
The components identified by mark  or dotted line with mark  are critical for safety. Replace only with part number specified.

Note:
Les composants identifiés par une marque  sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.


Ref.No	Part No.	Description	Remarks	Ref.No	Part No.	Description	Remarks
51	*4-930-252-01	PLATE, SHIELD		60	4-930-206-01	HANDLE	
52	*4-930-207-01	CASE, BATTERY RECEIVE		61	*1-629-992-11	PC BOARD, POWER	
53	3-365-853-01	SCREW +BTPWH 3X12		62	3-831-441-XX	CUSHION, SPEAKER	
54	1-533-217-31	HOLDER, FUSE		63	3-713-907-01	SPACER, CAM	
55	4-920-988-01	SPRING (MINUS)		64	3-365-847-01	CABINET (REAR) (US)	
56	4-930-222-01	SPRING (A)		64	3-365-847-11	CABINET (REAR) (Canadian)	
57	3-365-846-01	TERMINAL, ANT		ANT1	1-501-383-21	ANTENNA, TELESCOPIC	
58	4-930-208-01	LID, BATTERY CASE		F901	 1-576-030-11	FUSE, GLASS TUBE (5A 125V)	
59	4-920-987-01	SPRING (C)		T901	 1-449-613-11	TRANSFORMER, POWER	

6-3. CD UNIT ASSEMBLY



Ref.No	Part No.	Description	Remarks	Ref.No	Part No.	Description	Remarks
101	X-4920-911-1	LID SUB ASSY, CD		115	4-922-858-01	DAMPER	
102	4-920-980-01	SPRING (CD)		116	4-922-858-11	DAMPER	
103	X-4920-910-1	PLATE ASSY, FULCRUM		117	4-931-373-01	SCREW, CD FITTING	
104	1-452-531-11	MAGNET		118	3-831-441-11	CUSHION	
105	4-925-922-11	COVER, CHUCKING		119	*1-629-995-11	PC BOARD, CD MOTOR	
106	3-704-435-01	PLATE (M), CHUCK		120	*4-930-246-11	PAPER (N), SHIELD	
107	3-365-837-01	WASHER		121	*A-3270-946-A	CD MAIN BOARD, COMPLETE	
108	4-930-216-01	CHASSIS (CD)		122	*1-629-994-11	PC BOARD, CD CONTROL	
109	*4-930-256-01	PLATE (LEFT)		123	4-934-512-01	CUSHION (LCD)	
110	3-343-248-01	DAMPER (P), SMALL		124	4-930-226-01	RETAINER, CD BUTTON	
111	3-362-140-01	CATCHER, PUSH		125	3-831-441-XX	SPACER	
112	*1-629-996-11	PC BOARD, CD LEAF SW		LCD1	1-808-930-11	DISPLAY PANEL, LIQUID CRYSTAL	
113	*4-928-936-01	COVER, CD		S801	1-570-822-21	SWITCH, LEAF (OPEN DET)	
114	4-931-358-01	SPRING		S802	1-571-936-11	SWITCH, LEAF (LIMIT IN)	

**6-4. OPTICAL BLOCK
(KSM-150BG)**




Ref.No	Part No.	Description	Remarks	Ref.No	Part No.	Description	Remarks
151	2-641-447-01	SCREW (2.6X8), + STP		157	*2-641-434-01	COVER, GEAR	
152	2-641-448-02	CLAMP, SHAFT		158	3-303-809-31	SCREW (M1.7X3.0), SPECIAL HEAD	
153	*4-910-431-01	SHAFT, SLIDE		159	2-641-403-05	GEAR (B)	
154	⚠8-848-137-11	DEVICE, OPTICAL KSS-150B(J)		160	2-641-404-02	GEAR (A)	
155	X-2640-771-1	TURNTABLE ASSY		M702	1-541-352-11	MOTOR, SPINDLE	
156	2-641-444-01	HOLDER (J), CHASSIS		M703	X-2641-357-1	MOTOR ASSY, SLED (WITH GEAR)	

Note:
The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety. Replace only with part number specified.

Note:
Les composants identifiés par une marque ⚠ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

6-5. MECHANISM BLOCK (1) (DECK A) (MF-460-64)




Ref.No	Part No.	Description	Remarks	Ref.No	Part No.	Description	Remarks
201	4-936-206-01	SLIDER (S), EJECT		214	4-928-982-01	LEVER (C)	
202	4-932-648-01	SPRING, COMPRESSION		215	X-4920-347-1	LEVER (S) ASSY, FR	
203	4-928-985-01	LEVER, STOP		216	4-928-978-01	GEAR (C), SUPPLY REEL	
204	4-921-195-01	LEVER (AC), REC		217	4-931-795-11	WASHER	
205	4-928-991-01	LEVER, PLAY		218	3-343-381-01	SPRING, COMPRESSION	
206	4-928-992-01	LEVER, REW		219	4-928-957-01	RETAINER, CASSETTE	
207	4-928-993-01	LEVER, FF		220	3-343-285-01	GEAR, FF	
208	4-928-994-01	LEVER, PAUSE		221	X-4920-350-1	GEAR (S) ASSY, T REEL	
209	3-313-372-01	SPRING, TENSION		222	4-932-656-01	SPRING, COMPRESSION	
210	4-928-973-01	SPRING		223	4-932-695-01	SLIDER (FR), LOCK	
211	4-928-972-01	SPRING, TENSION		224	4-928-976-01	LEVER, SW	
212	4-932-693-02	DECK (S), HEAD		HP301	1-543-628-11	HEAD, MAGNETIC (REC/PB)	
213	4-928-962-01	PINCH ROLLER					

6-6. MECHANISM BLOCK (2) (DECK A) (MF-460-64)

Ⓐ: See page 41


Ⓑ: See page 41

Ⓒ: See page 41



Ref.No	Part No.	Description	Remarks	Ref.No	Part No.	Description	Remarks
251	3-322-527-01	SPRING, TENSION		260	4-932-655-01	SPRING, COMPRESSION	
252	*X-4918-598-1	PLATE ASSY, GROUND		261	4-928-986-01	LEVER (S), SHUT-OFF	
253	4-928-974-01	BELT (MIDWAY)		262	X-4918-582-1	PLATE ASSY, TAKE-UP REEL	
254	4-934-520-01	BELT		263	4-928-958-01	SPRING, FR RETURN	
255	X-4920-923-1	WHEEL (W) ASSY, CAPSTAN		264	A-3208-379-A	CHASSIS (S) ASSY, MECHANISM	
256	4-928-987-01	LEVER (T), SHUT-OFF		265	3-343-358-01	RING, RETAINING	
257	X-4920-922-1	PULLEY (W) ASSY, FR		266	4-928-967-01	GEAR (C), MIDWAY	
258	4-928-961-01	PLATE, PAUSE LOCK		267	4-928-996-01	LEVER, SW	
259	X-4920-346-1	LEVER (S) ASSY, IDLER		268	4-932-656-01	SPRING, COMPRESSION	

6-7. MECHANISM BLOCK (3) (DECK B) (MF-460-64)




Ref.No	Part No.	Description	Remarks	Ref.No	Part No.	Description	Remarks
301	4-936-206-01	SLIDER (S), EJECT		314	4-928-982-01	LEVER (C)	
302	4-932-648-01	SPRING, COMPRESSION		315	X-4920-347-1	LEVER (S) ASSY, FR	
303	4-928-985-01	LEVER, STOP		316	4-928-978-01	GEAR (C), SUPPLY REEL	
304	4-934-511-01	LEVER (S), REC		317	4-931-795-11	WASHER	
305	4-928-991-01	LEVER, PLAY		318	3-343-381-01	SPRING, COMPRESSION	
306	4-928-992-01	LEVER, REW		319	4-928-957-01	RETAINER, CASSETTE	
307	4-928-993-01	LEVER, FF		320	3-343-285-01	GEAR, FF	
308	4-928-994-01	LEVER, PAUSE		321	X-4920-350-1	GEAR (S) ASSY, T REEL	
309	3-313-372-01	SPRING, TENSION		322	4-932-656-01	SPRING, COMPRESSION	
310	4-928-973-01	SPRING		323	4-932-695-01	SLIDER (FR), LOCK	
311	4-928-972-01	SPRING, TENSION		324	4-928-960-02	CLAW, SAFETY	
312	4-932-693-02	DECK (S), HEAD		HE301	1-543-525-11	HEAD, MAGNETIC (ERASE)	
313	4-928-962-01	PINCH ROLLER		HRP301	1-543-628-11	HEAD, MAGNETIC (REC/PB)	

6-8. MECHANISM BLOCK (4) (DECK B) (MF-460-64)

Ⓐ: See page 39


Ⓑ: See page 39

Ⓒ: See page 39



Ref.No	Part No.	Description	Remarks	Ref.No	Part No.	Description	Remarks
351	4-934-522-01	CUSHION		361	4-928-986-01	LEVER (S), SHUT-OFF	
352	X-4920-921-1	PLATE (W) ASSY, GROUND		362	X-4918-582-1	PLATE ASSY, TAKE-UP REEL	
353	4-928-974-01	BELT (MIDWAY)		363	4-928-958-01	SPRING, FR RETURN	
354	4-934-521-01	BELT		364	A-3208-379-A	CHASSIS (S) ASSY, MECHANISM	
355	X-4920-923-1	WHEEL (W) ASSY, CAPSTAN		365	3-343-358-01	RING, RETAINING	
356	4-928-987-01	LEVER (T), SHUT-OFF		366	4-928-967-01	GEAR (C), MIDWAY	
357	X-4920-922-1	PULLEY (W) ASSY, FR		367	4-928-996-01	LEVER, SW	
358	4-928-961-01	PLATE, PAUSE LOCK		368	4-932-656-01	SPRING, COMPRESSION	
359	X-4920-346-1	LEVER (S) ASSY, IDLER		369	3-343-251-01	SCREW (M2.6X2.5)	
360	4-932-655-01	SPRING, COMPRESSION		M301	X-4920-924-1	MOTOR ASSY	

6-9. SPEAKER ASSEMBLY



Ref.No	Part No.	Description	Remarks	Ref.No	Part No.	Description	Remarks
401	X-3362-584-1	BOX (L) ASSY, SP		405	4-930-231-01	FOOT	
401	X-3362-585-1	BOX (R) ASSY, SP		406	1-529-058-11	BUZZER	
402	1-559-620-11	CORD (WITH CONNECTOR)		407	1-544-102-11	SPEAKER	
403	*4-930-212-01	LID, REAR, SP		408	4-925-334-31	EMBLEM (5-A), SONY	
404	3-831-441-XX	CUSHION, SPEAKER					

SECTION 7 ELECTRICAL PARTS LIST

AUDIO MAIN

NOTE:

- Due to standardization, replacements in the parts list may be different from the parts specified in the diagrams or the components used on the set.
- Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- If there are two or more same circuits in a set such as a stereophonic machine, only typical circuit parts may be indicated and capacitors and resistors in other same circuits may be omitted.

CAPACITORS:MF: μ F, PF: μ F.**RESISTORS**

- All resistors are in ohms.
- F: nonflammable

COILS

- MMH: mH, UH: μ H

SEMICONDUCTORSIn each case, U: μ , for example:UA...: μ A..., UPA...: μ PA...,UPC...: μ PC, UPD...: μ PD...

- Screw (#mark) list is given in the last of this parts list.

The components identified by mark  or dotted line with mark  are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque  sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

Ref.No	Part No.	Description	Remark	Ref.No	Part No.	Description	Remark
*A-3261-419-A AUDIO MAIN BOARD, COMPLETE *****				C123	1-136-169-00	FILM	0.22MF 5% 50V
				C200	1-162-294-31	CERAMIC	0.001MF 10% 50V
				C201	1-162-291-31	CERAMIC	560PF 10% 50V
				C202	1-162-291-31	CERAMIC	560PF 10% 50V
				C203	1-162-286-31	CERAMIC	220PF 10% 50V
				C204	1-162-286-31	CERAMIC	220PF 10% 50V
				C205	1-124-126-00	ELECT	47MF 20% 10V
				C206	1-161-054-00	CERAMIC	0.018MF 10% 25V
				C207	1-124-791-11	ELECT	1MF 20% 50V
				C209	1-124-791-11	ELECT	1MF 20% 50V
				C210	1-162-294-31	CERAMIC	0.001MF 10% 50V
				C211	1-124-126-00	ELECT	47MF 20% 10V
				C212	1-162-294-31	CERAMIC	0.001MF 10% 50V
				C213	1-162-294-31	CERAMIC	0.001MF 10% 50V
				C214	1-124-791-11	ELECT	1MF 20% 50V
				C215	1-162-290-31	CERAMIC	470PF 10% 50V
				C216	1-124-791-11	ELECT	1MF 20% 50V
				C217	1-124-927-11	ELECT	4.7MF 20% 50V
				C218	1-124-927-11	ELECT	4.7MF 20% 50V
				C219	1-161-375-00	CERAMIC	0.0022MF 30% 16V
				C220	1-124-443-00	ELECT	100MF 20% 10V
				C221	1-124-443-00	ELECT	100MF 20% 10V
				C222	1-124-473-11	ELECT	1000MF 20% 10V
				C223	1-136-169-00	FILM	0.22MF 5% 50V
				C301	1-130-470-00	MYLAR	820PF 5% 50V
				C302	1-130-473-00	MYLAR	0.0015MF 5% 50V
				C303	1-130-482-00	MYLAR	0.0082MF 5% 50V
				C304	1-124-126-00	ELECT	47MF 20% 10V
				C305	1-130-479-00	MYLAR	0.0047MF 5% 50V
				C307	1-124-126-00	ELECT	47MF 20% 10V
				C308	1-123-875-11	ELECT	10MF 20% 50V
				C309	1-124-925-11	ELECT	2.2MF 20% 50V
				C310	1-126-176-11	ELECT	220MF 20% 10V
				C311	1-124-925-11	ELECT	2.2MF 20% 50V
				C312	1-123-875-11	ELECT	10MF 20% 50V
				C313	1-124-034-51	ELECT	33MF 20% 16V
				C314	1-124-902-00	ELECT	0.47MF 20% 50V
				C315	1-162-282-31	CERAMIC	100PF 10% 50V
				C316	1-162-282-31	CERAMIC	100PF 10% 50V
				C317	1-161-377-00	CERAMIC	0.0047MF 30% 16V
				C318	1-124-443-00	ELECT	100MF 20% 10V
				C319	1-124-927-11	ELECT	4.7MF 20% 50V
				C320	1-124-443-00	ELECT	100MF 20% 10V
				C321	1-124-120-11	ELECT	220MF 20% 16V
				C322	1-162-294-31	CERAMIC	0.001MF 10% 50V
				C323	1-123-875-11	ELECT	10MF 20% 50V
				C324	1-124-480-11	ELECT	470MF 20% 25V
				C325	1-161-379-00	CERAMIC	0.01MF 30% 16V
				C326	1-161-379-00	CERAMIC	0.01MF 30% 16V
				C327	1-124-120-11	ELECT	220MF 20% 16V
				C328	1-124-120-11	ELECT	220MF 20% 16V
				C329	1-161-379-00	CERAMIC	0.01MF 30% 16V
				C330	1-161-379-00	CERAMIC	0.01MF 30% 16V
				C331	1-124-120-11	ELECT	220MF 20% 16V
				C332	1-124-120-11	ELECT	220MF 20% 16V

AUDIO MAIN

Ref.No	Part No.	Description	Remark		
C333	1-124-120-11	ELECT	220MF	20%	16V
C334	1-161-379-00	CERAMIC	0.01MF	30%	16V
C335	1-124-120-11	ELECT	220MF	20%	16V
C336	1-161-379-00	CERAMIC	0.01MF	30%	16V
C337	1-124-902-00	ELECT	0.47MF	20%	50V
C338	1-161-379-00	CERAMIC	0.01MF	30%	16V
C339	1-123-875-11	ELECT	10MF	20%	50V
C340	1-124-443-00	ELECT	100MF	20%	10V
C347	1-124-902-00	ELECT	0.47MF	20%	50V
C351	1-124-925-11	ELECT	2.2MF	20%	50V

CERAMIC FILTER

CF1	1-577-599-81	FILTER, CERAMIC
CF2	1-577-599-81	FILTER, CERAMIC
CF3	1-577-599-81	FILTER, CERAMIC

CONNECTOR

CNP301	*1-506-986-11	PIN, CONNECTOR (PC BOARD) 4P
CNP302	*1-506-986-11	PIN, CONNECTOR (PC BOARD) 4P
CNP303	*1-566-824-11	PIN, CONNECTOR (PC BOARD) 3P
CNP304	*1-506-988-11	PIN, CONNECTOR (PC BOARD) 6P
CNP305	*1-565-302-11	PIN, CONNECTOR (PC BOARD) 6P

CNP306	*1-566-973-11	PIN, CONNECTOR (PC BOARD) 8P
CNP309	*1-506-990-11	PIN, CONNECTOR (PC BOARD) 8P

COMBINATION PARTS

CP1	1-236-079-11	ENCAPSULATED COMPONENT
-----	--------------	------------------------

VARIABLE CAPACITOR

CT1-4 CV1-4	1-151-624-11	CAP, VARIABLE
----------------	--------------	---------------

DIODE

D1	8-719-911-19	DIODE 1SS119
D2	8-719-911-19	DIODE 1SS119
D3	8-719-304-78	DIODE SEL2210R-D
D301	8-719-911-19	DIODE 1SS119
D302	8-719-911-19	DIODE 1SS119
D303	8-719-911-19	DIODE 1SS119
D304	8-719-109-97	DIODE RD6.8ES-B2
D305	8-719-911-19	DIODE 1SS119
D306	8-719-304-78	DIODE SEL2210R-D
D307	8-719-921-75	DIODE MTZN-10B
D308	8-719-109-93	DIODE RD6.2ES-B2
D309	8-719-921-75	DIODE MTZN-10B
D310	8-719-911-19	DIODE 1SS119
D311	8-719-911-19	DIODE 1SS119
D312	8-719-911-19	DIODE 1SS119

D313	8-719-109-93	DIODE RD6.2ES-B2
------	--------------	------------------

FILTER

FL1	1-236-022-11	FILTER, BAND PASS
-----	--------------	-------------------

IC

IC1	8-752-035-68	IC CXA1238S
IC301	8-759-242-58	IC TA8189N
IC302	8-752-052-45	IC CXA1352S
IC303	8-759-820-22	IC LA4597

JACK

J301	1-563-330-11	JACK (MIX MIC)
J302	1-566-891-11	JACK (PHONES)
J303	1-537-114-11	TERMINAL BOARD (SPEAKER OUT)

Ref.No	Part No.	Description	Remark		
--------	----------	-------------	--------	--	--

COIL

L1	*1-428-029-11	COIL, AIR-CORE			
L2	*1-422-354-11	COIL, AIR-CORE			
L3	1-402-435-11	ANTENNA, FERRITE-ROD (MW)			
L4	1-408-417-00	INDUCTOR 47UH			

TRANSISTOR

Q5	1-807-870-11	TRANSISTOR KSR1008			
Q6	1-807-870-11	TRANSISTOR KSR1008			
Q102	1-807-870-11	TRANSISTOR KSR1008			
Q202	1-807-870-11	TRANSISTOR KSR1008			
Q301	1-807-868-11	TRANSISTOR KSR1006			
Q302	1-807-868-11	TRANSISTOR KSR1006			
Q303	1-807-543-11	TRANSISTOR KSC1008-R			
Q304	8-729-119-76	TRANSISTOR 2SA1175-HFE			
Q305	8-729-119-78	TRANSISTOR 2SC2785-HFE			
Q306	8-729-905-67	TRANSISTOR 2SD1944-K			
Q308	1-807-868-11	TRANSISTOR KSR1006			
Q309	8-729-107-26	TRANSISTOR 2SD1815-K			
Q311	1-807-868-11	TRANSISTOR KSR1006			
Q313	8-729-107-26	TRANSISTOR 2SD1815-K			
Q319	8-729-119-78	TRANSISTOR 2SC2785-HFE			
Q320	1-807-868-11	TRANSISTOR KSR1006			
Q321	8-729-119-78	TRANSISTOR 2SC2785-HFE			
Q322	8-729-119-78	TRANSISTOR 2SC2785-HFE			
Q323	1-807-868-11	TRANSISTOR KSR1006			

RESISTOR

R1	1-249-441-11	CARBON	100K	5%	1/4W
R2	1-249-421-11	CARBON	2.2K	5%	1/4W
R3	1-249-415-11	CARBON	680	5%	1/4W
R4	1-249-407-11	CARBON	150	5%	1/4W
R5	1-249-401-11	CARBON	47	5%	1/4W
R6	1-249-427-11	CARBON	6.8K	5%	1/4W
R7	1-249-427-11	CARBON	6.8K	5%	1/4W
R8	1-247-887-00	CARBON	220K	5%	1/4W
R9	1-247-887-00	CARBON	220K	5%	1/4W
R10	1-249-421-11	CARBON	2.2K	5%	1/4W
R11	1-249-429-11	CARBON	10K	5%	1/4W
R12	1-249-409-11	CARBON	220	5%	1/4W
R14	1-249-426-11	CARBON	5.6K	5%	1/4W
R16	1-249-397-11	CARBON	22	5%	1/4W
R50	1-249-429-11	CARBON	10K	5%	1/4W
R51	1-249-429-11	CARBON	10K	5%	1/4W
R101	1-249-425-11	CARBON	4.7K	5%	1/4W
R102	1-249-439-11	CARBON	68K	5%	1/4W
R103	1-249-417-11	CARBON	1K	5%	1/4W
R104	1-249-417-11	CARBON	1K	5%	1/4W
R105	1-247-885-00	CARBON	180K	5%	1/4W
R106	1-249-427-11	CARBON	6.8K	5%	1/4W
R107	1-249-429-11	CARBON	10K	5%	1/4W
R108	1-249-421-11	CARBON	2.2K	5%	1/4W
R109	1-249-427-11	CARBON	6.8K	5%	1/4W
R110	1-249-405-11	CARBON	100	5%	1/4W
R111	1-249-422-11	CARBON	2.7K	5%	1/4W
R112	1-247-870-11	CARBON	43K	5%	1/4W
R113	1-249-421-11	CARBON	2.2K	5%	1/4W
R114	1-249-421-11	CARBON	2.2K	5%	1/4W
R115	1-247-890-11	CARBON	300K	5%	1/4W
R116	1-249-407-11	CARBON	150	5%	1/4W
R117	1-247-885-00	CARBON	180K	5%	1/4W
R118	1-249-426-11	CARBON	5.6K	5%	1/4W
R119	1-249-430-11	CARBON	12K	5%	1/4W
R120	1-249-423-11	CARBON	3.3K	5%	1/4W
R121	1-249-435-11	CARBON	33K	5%	1/4W

AUDIO MAIN

CD CONTROL

CD LEAF SW

CD MAIN

Ref.No	Part No.	Description			Remark
R122	1-249-431-11	CARBON	15K	5%	1/4W
R123	1-249-425-11	CARBON	4.7K	5%	1/4W
R124	1-249-406-11	CARBON	120	5%	1/4W
R125	1-249-427-11	CARBON	6.8K	5%	1/4W
R201	1-249-425-11	CARBON	4.7K	5%	1/4W
R202	1-249-439-11	CARBON	68K	5%	1/4W
R203	1-249-417-11	CARBON	1K	5%	1/4W
R204	1-249-417-11	CARBON	1K	5%	1/4W
R205	1-247-885-00	CARBON	180K	5%	1/4W
R206	1-249-427-11	CARBON	6.8K	5%	1/4W
R207	1-249-429-11	CARBON	10K	5%	1/4W
R208	1-249-421-11	CARBON	2.2K	5%	1/4W
R209	1-249-427-11	CARBON	6.8K	5%	1/4W
R210	1-249-405-11	CARBON	100	5%	1/4W
R211	1-249-422-11	CARBON	2.7K	5%	1/4W
R212	1-247-870-11	CARBON	43K	5%	1/4W
R213	1-249-421-11	CARBON	2.2K	5%	1/4W
R214	1-249-421-11	CARBON	2.2K	5%	1/4W
R215	1-247-890-11	CARBON	300K	5%	1/4W
R216	1-249-407-11	CARBON	150	5%	1/4W
R217	1-247-885-00	CARBON	180K	5%	1/4W
R218	1-249-426-11	CARBON	5.6K	5%	1/4W
R219	1-249-430-11	CARBON	12K	5%	1/4W
R220	1-249-423-11	CARBON	3.3K	5%	1/4W
R221	1-249-435-11	CARBON	33K	5%	1/4W
R222	1-249-431-11	CARBON	15K	5%	1/4W
R223	1-249-425-11	CARBON	4.7K	5%	1/4W
R224	1-249-406-11	CARBON	120	5%	1/4W
R225	1-249-427-11	CARBON	6.8K	5%	1/4W
R304	1-249-409-11	CARBON	220	5%	1/4W
R305	1-249-417-11	CARBON	1K	5%	1/4W
R306	1-249-435-11	CARBON	33K	5%	1/4W
R307	1-249-389-11	CARBON	4.7	5%	1/4W
R308	1-249-432-11	CARBON	18K	5%	1/4W
R309	1-249-429-11	CARBON	10K	5%	1/4W
R310	1-249-429-11	CARBON	10K	5%	1/4W
R311	1-249-431-11	CARBON	15K	5%	1/4W
R312	1-249-421-11	CARBON	2.2K	5%	1/4W
R313	1-249-402-11	CARBON	56	5%	1/4W
R314	1-249-423-11	CARBON	3.3K	5%	1/4W
R315	1-249-418-11	CARBON	1.2K	5%	1/4W
R316	1-247-903-00	CARBON	1M	5%	1/4W
R317	1-247-884-11	CARBON	160K	5%	1/4W
R318	1-247-901-11	CARBON	820K	5%	1/4W
R319	△ 1-249-381-11	CARBON	1	5%	1/4W F
R320	1-249-417-11	CARBON	1K	5%	1/4W
R321	1-249-409-11	CARBON	220	5%	1/4W
R322	1-249-418-11	CARBON	1.2K	5%	1/4W
R323	△ 1-217-639-00	FUSIBLE	2.2	5%	1/4W F
R324	1-249-423-11	CARBON	3.3K	5%	1/4W
R325	1-249-415-11	CARBON	680	5%	1/4W
R326	△ 1-212-938-00	FUSIBLE	1.5	5%	1/2W F
R327	1-249-411-11	CARBON	330	5%	1/4W
R328	1-249-413-11	CARBON	470	5%	1/4W
R330	1-249-425-11	CARBON	4.7K	5%	1/4W
R332	△ 1-249-383-11	CARBON	1.5	5%	1/4W F
R336	1-247-804-11	CARBON	75	5%	1/4W
R337	1-249-411-11	CARBON	330	5%	1/4W
R338	1-249-429-11	CARBON	10K	5%	1/4W
R339	1-249-425-11	CARBON	4.7K	5%	1/4W
R340	1-249-410-11	CARBON	270	5%	1/4W
R341	1-249-421-11	CARBON	2.2K	5%	1/4W
R342	1-247-895-00	CARBON	470K	5%	1/4W
R343	1-249-427-11	CARBON	6.8K	5%	1/4W
R344	1-249-427-11	CARBON	6.8K	5%	1/4W

Ref.No	Part No.	Description			Remark
R345	1-249-437-11	CARBON	47K	5%	1/4W
R346	1-249-426-11	CARBON	5.6K	5%	1/4W
R347	1-249-407-11	CARBON	150	5%	1/4W
R348	1-249-418-11	CARBON	1.2K	5%	1/4W
R350	1-249-428-11	CARBON	8.2K	5%	1/4W
R351	1-249-409-11	CARBON	220	5%	1/4W
R353	1-249-428-11	CARBON	8.2K	5%	1/4W
R354	1-249-417-11	CARBON	1K	5%	1/4W

VARIABLE RESISTOR

RV1	1-238-017-11	RES, ADJ, CARBON 22K
RV302	1-238-480-11	RES, VAR, CARBON 50K (VOLUME)

SWITCH

S1	1-572-668-11	SWITCH, LEVER SLIDE (BAND)
S301	1-570-916-11	SWITCH, SLIDE (REC/PB)
S302	1-572-669-11	SWITCH, LEVER SLIDE (FUNCTION)
S303	1-571-307-11	SWITCH, SLIDE (ISS)

TRANSFORMER

T1	1-406-040-00	COIL (OSC)
T301	1-433-332-11	OSCILLATION TRANSFORMER, BIAS

*1-629-994-11 CD CONTROL BOARD

CONNECTOR

CN811	*1-568-451-11	HOUSING,CONNECTOR(PC BOARD)10P
CN812	*1-568-451-11	HOUSING,CONNECTOR(PC BOARD)10P
CN813	*1-568-451-11	HOUSING,CONNECTOR(PC BOARD)10P

INDICATOR

LCD1	1-808-930-11	DISPLAY PANEL, LIQUID CRYSTAL
------	--------------	-------------------------------

SWITCH

S803	1-571-530-11	SWITCH, KEY BOARD (PLAY ►)
S804	1-571-530-11	SWITCH, KEY BOARD (STOP ■)
S805	1-571-530-11	SWITCH, KEY BOARD (AMS SEARCH ►►)
S806	1-571-530-11	SWITCH, KEY BOARD (AMS SEARCH ◄◄)
S807	1-571-530-11	SWITCH, KEY BOARD (PAUSE)
S808	1-571-530-11	SWITCH, KEY BOARD (PLAY MODE)
S809	1-571-530-11	SWITCH, KEY BOARD (REMAIN/ENTER)

*1-629-996-11 CD LEAF SW BOARD

CONNECTOR

W716	1-506-569-11	PIN, CONNECTOR 3P
------	--------------	-------------------

A-3270-946-A CD MAIN BOARD, COMPLETE

CAPACITOR

C701	1-130-475-00	MYLAR	0.0022MF	5%	50V
C702	1-124-034-51	ELECT	33MF	20%	16V
C703	1-162-294-31	CERAMIC	0.001MF	10%	50V
C704	1-124-443-00	ELECT	100MF	20%	6.3V
C705	1-126-176-11	ELECT	220MF	20%	6.3V

Note:

The components identified by mark △ or dotted line with mark △ are critical for safety. Replace only with part number specified.

Note:

Les composants identifiés par une marque △ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

CD MAIN

Ref.No	Part No.	Description	Remark		
C706	1-130-489-00	MYLAR	0.033MF	5%	50V
C707	1-131-374-00	TANTALUM	33MF	10%	3.15V
C708	1-130-489-00	MYLAR	0.033MF	5%	50V
C709	1-130-483-00	MYLAR	0.01MF	5%	50V
C710	1-124-034-51	ELECT	33MF	20%	16V
C711	1-162-207-31	CERAMIC	22PF	5%	50V
C712	1-162-207-31	CERAMIC	22PF	5%	50V
C713	1-124-472-11	ELECT	470MF	20%	10V
C714	1-161-379-00	CERAMIC	0.01MF	30%	16V
C715	1-136-173-00	FILM	0.47MF	5%	50V
C716	1-130-483-00	MYLAR	0.01MF	5%	50V
C717	1-162-294-31	CERAMIC	0.001MF	10%	50V
C718	1-124-902-00	ELECT	0.47MF	20%	50V
C719	1-162-851-11	CERAMIC	0.1MF	10%	16V
C720	1-130-489-00	MYLAR	0.033MF	5%	50V
C721	1-124-034-51	ELECT	33MF	20%	16V
C722	1-130-475-00	MYLAR	0.0022MF	5%	50V
C723	1-161-021-11	CERAMIC	0.047MF	10%	25V
C724	1-162-294-31	CERAMIC	0.001MF	10%	50V
C725	1-136-165-00	FILM	0.1MF	5%	50V
C726	1-136-165-00	FILM	0.1MF	5%	50V
C727	1-124-034-51	ELECT	33MF	20%	16V
C728	1-131-377-00	TANTALUM	10MF	10%	6.3V
C729	1-136-165-00	FILM	0.1MF	5%	50V
C730	1-123-875-11	ELECT	10MF	20%	50V
C731	1-161-061-11	CERAMIC	0.068MF	10%	25V
C732	1-162-215-31	CERAMIC	47PF	5%	50V
C733	1-124-034-51	ELECT	33MF	20%	16V
C734	1-130-481-00	MYLAR	0.0068MF	5%	50V
C735	1-162-284-31	CERAMIC	150PF	10%	50V
C736	1-161-379-00	CERAMIC	0.01MF	30%	16V
C737	1-161-379-00	CERAMIC	0.01MF	30%	16V
C738	1-161-379-00	CERAMIC	0.01MF	30%	16V
C739	1-161-379-00	CERAMIC	0.01MF	30%	16V
C740	1-124-034-51	ELECT	33MF	20%	16V
C743	1-130-479-00	MYLAR	0.0047MF	5%	50V
C744	1-124-791-11	ELECT	1MF	20%	50V
C745	1-130-475-00	MYLAR	0.0022MF	5%	50V
C746	1-130-469-00	MYLAR	680PF	5%	50V
C747	1-102-960-00	CERAMIC	24PF	5%	50V
C748	1-126-176-11	ELECT	220MF	20%	6.3V
C749	1-124-791-11	ELECT	1MF	20%	50V
C750	1-130-488-00	MYLAR	0.027MF	5%	50V
C751	1-124-791-11	ELECT	1MF	20%	50V
C752	1-124-604-00	ELECT	330MF	20%	10V
C753	1-126-176-11	ELECT	220MF	20%	6.3V
C754	1-126-301-11	ELECT	1MF	20%	50V
C755	1-130-475-00	MYLAR	0.0022MF	5%	50V
C756	1-130-469-00	MYLAR	680PF	5%	50V
C757	1-102-960-00	CERAMIC	24PF	5%	50V
C758	1-124-791-11	ELECT	1MF	20%	50V
C759	1-124-791-11	ELECT	1MF	20%	50V
C760	1-130-488-00	MYLAR	0.027MF	5%	50V
C761	1-136-173-00	FILM	0.47MF	5%	50V
C763	1-162-199-31	CERAMIC	10PF	5%	50V
C764	1-162-199-31	CERAMIC	10PF	5%	50V
C765	1-162-294-31	CERAMIC	0.001MF	10%	50V
C770	1-124-360-00	ELECT	1000MF	20%	16V
C771	1-124-791-11	ELECT	1MF	20%	50V
C780	1-124-034-51	ELECT	33MF	20%	16V
C781	1-124-034-51	ELECT	33MF	20%	16V
C784	1-126-176-11	ELECT	220MF	20%	6.3V
C790	1-161-379-00	CERAMIC	0.01MF	30%	16V
C791	1-124-927-11	ELECT	4.7MF	20%	50V
C792	1-124-791-11	ELECT	1MF	20%	50V

Ref.No	Part No.	Description	Remark		
C794	1-124-791-11	ELECT	1MF	20%	50V
C801	1-124-034-51	ELECT	33MF	20%	16V
C802	1-161-379-00	CERAMIC	0.01MF	30%	16V
C803	1-162-219-31	CERAMIC	68PF	5%	50V
C804	1-162-219-31	CERAMIC	68PF	5%	50V
C851	1-162-292-31	CERAMIC	680PF	10%	50V
C852	1-162-215-31	CERAMIC	47PF	5%	50V
C853	1-162-215-31	CERAMIC	47PF	5%	50V
C856	1-162-294-31	CERAMIC	0.001MF	10%	50V

CONNECTOR

CN701	*1-564-710-11	PIN, CONNECTOR (SMALL TYPE) 8P
CN702	*1-564-710-11	PIN, CONNECTOR (SMALL TYPE) 8P
CN703	*1-506-988-11	PIN, CONNECTOR (PC BOARD) 6P
CN704	*1-506-988-11	PIN, CONNECTOR (PC BOARD) 6P
CN705	*1-506-985-11	PIN, CONNECTOR (PC BOARD) 3P
CN706	*1-562-477-11	CONNECTOR (SOCKET) 3P
W801	*1-568-455-11	PIN, CONNECTOR (PC BOARD) 10P
W802	*1-568-455-11	PIN, CONNECTOR (PC BOARD) 10P
W803	*1-568-455-11	PIN, CONNECTOR (PC BOARD) 10P

DIODE

D701	8-719-911-19	DIODE 1SS119
D702	8-719-911-19	DIODE 1SS119
D801	8-719-911-19	DIODE 1SS119
D802	8-719-911-19	DIODE 1SS119
D804	8-719-911-19	DIODE 1SS119
D805	8-719-911-19	DIODE 1SS119

IC

IC701	8-752-033-14	IC CXA1081Q
IC702	8-752-032-32	IC CXA1182Q-Z
IC703	8-752-328-46	IC CXD1130Q
IC704	8-759-984-09	IC LH5116NA-10
IC706	8-759-710-98	IC NJM2100D
IC707	8-759-148-30	IC UPD6376GS
IC708	8-759-501-65	IC BA6294
IC709	8-759-501-65	IC BA6294
IC801	8-752-814-10	IC CXP5024-092Q
IC802	1-807-547-11	IC MC4558-C
IC804	8-759-971-11	IC PST529D

COIL

L701	1-410-316-11	INDUCTOR 1UH
L702	1-410-678-31	INDUCTOR 220UH
L703	1-410-316-11	INDUCTOR 1UH
L704	1-410-678-31	INDUCTOR 220UH
L705	1-424-090-11	COIL, LINE FILTER

TRANSISTOR

Q701	8-729-801-84	TRANSISTOR 2SB1013
Q702	8-729-119-78	TRANSISTOR 2SC2785-HFE
Q703	8-729-119-78	TRANSISTOR 2SC2785-HFE
Q704	8-729-119-78	TRANSISTOR 2SC2785-HFE
Q705	1-807-877-11	TRANSISTOR KSR2003
Q706	8-729-119-76	TRANSISTOR 2SA1175-HFE
Q711	1-807-865-11	TRANSISTOR KSR1003
Q712	8-729-119-78	TRANSISTOR 2SC2785-HFE
Q713	8-729-119-78	TRANSISTOR 2SC2785-HFE
Q714	1-807-877-11	TRANSISTOR KSR2003
Q791	1-807-865-11	TRANSISTOR KSR1003
Q792	1-807-865-11	TRANSISTOR KSR1003
Q801	1-807-877-11	TRANSISTOR KSR2003
Q802	1-807-871-11	TRANSISTOR KSR1009
Q803	8-729-119-78	TRANSISTOR 2SC2785-HFE

CD MAIN

CD MOTOR

GEQ VOL

Ref.No	Part No.	Description	Remark		
RESISTOR					
R701	1-249-433-11	CARBON	22K	5%	1/4W
R702	1-249-417-11	CARBON	1K	5%	1/4W
R703	1-249-433-11	CARBON	22K	5%	1/4W
R704	1-249-397-11	CARBON	22	5%	1/4W
R705	1-247-806-11	CARBON	91	5%	1/4W
R711	1-249-428-11	CARBON	8.2K	5%	1/4W
R712	1-247-856-00	CARBON	11K	5%	1/4W
R713	1-249-441-11	CARBON	100K	5%	1/4W
R714	1-249-425-11	CARBON	4.7K	5%	1/4W
R715	1-249-441-11	CARBON	100K	5%	1/4W
R716	1-247-886-11	CARBON	200K	5%	1/4W
R717	1-249-422-11	CARBON	2.7K	5%	1/4W
R718	1-247-903-00	CARBON	1M	5%	1/4W
R719	1-249-417-11	CARBON	1K	5%	1/4W
R720	1-247-883-00	CARBON	150K	5%	1/4W
R721	1-249-437-11	CARBON	47K	5%	1/4W
R722	1-249-429-11	CARBON	10K	5%	1/4W
R723	1-249-441-11	CARBON	100K	5%	1/4W
R724	1-249-438-11	CARBON	56K	5%	1/4W
R725	1-247-885-00	CARBON	180K	5%	1/4W
R726	1-249-437-11	CARBON	47K	5%	1/4W
R727	1-249-441-11	CARBON	100K	5%	1/4W
R728	1-247-854-11	CARBON	9.1K	5%	1/4W
R729	1-247-894-11	CARBON	430K	5%	1/4W
R730	1-249-441-11	CARBON	100K	5%	1/4W
R731	1-215-457-00	METAL	33K	1%	1/6W
R732	1-215-457-00	METAL	33K	1%	1/6W
R733	1-247-895-00	CARBON	470K	5%	1/4W
R734	1-249-417-11	CARBON	1K	5%	1/4W
R735	1-249-417-11	CARBON	1K	5%	1/4W
R736	1-249-429-11	CARBON	10K	5%	1/4W
R743	1-215-438-00	METAL	5.1K	1%	1/6W
R744	1-215-456-00	METAL	30K	1%	1/6W
R745	1-215-454-00	METAL	24K	1%	1/6W
R746	1-215-471-00	METAL	120K	1%	1/6W
R747	1-249-431-11	CARBON	15K	5%	1/4W
R748	1-249-422-11	CARBON	2.7K	5%	1/4W
R749	1-247-834-11	CARBON	1.3K	5%	1/4W
R750	1-249-414-11	CARBON	560	5%	1/4W
R751	1-247-903-00	CARBON	1M	5%	1/4W
R752	1-249-430-11	CARBON	12K	5%	1/4W
R753	1-215-438-00	METAL	5.1K	1%	1/6W
R754	1-215-456-00	METAL	30K	1%	1/6W
R755	1-215-454-00	METAL	24K	1%	1/6W
R756	1-215-471-00	METAL	120K	1%	1/6W
R757	1-247-887-00	CARBON	220K	5%	1/4W
R758	1-249-422-11	CARBON	2.7K	5%	1/4W
R759	1-247-834-11	CARBON	1.3K	5%	1/4W
R760	1-249-414-11	CARBON	560	5%	1/4W
R761	1-247-903-00	CARBON	1M	5%	1/4W
R762	1-249-422-11	CARBON	2.7K	5%	1/4W
R763	1-249-422-11	CARBON	2.7K	5%	1/4W
R764	1-247-887-00	CARBON	220K	5%	1/4W
R765	1-249-395-11	CARBON	15	5%	1/4W
R766	1-249-401-11	CARBON	47	5%	1/4W
R768	1-249-405-11	CARBON	100	5%	1/4W
R770	1-215-453-00	METAL	22K	1%	1/6W
R771	1-215-453-00	METAL	22K	1%	1/6W
R772	1-215-453-00	METAL	22K	1%	1/6W
R773	1-215-453-00	METAL	22K	1%	1/6W
R774	1-215-429-00	METAL	2.2K	1%	1/6W
R775	1-215-457-00	METAL	33K	1%	1/6W
R776	1-215-457-00	METAL	33K	1%	1/6W
R777	1-215-457-00	METAL	33K	1%	1/6W

Ref.No	Part No.	Description	Remark		
R778	1-215-433-00	METAL	3.3K	1%	1/6W
R779	1-247-868-11	CARBON	36K	5%	1/4W
R780	1-249-435-11	CARBON	33K	5%	1/4W
R781	1-247-876-11	CARBON	75K	5%	1/4W
R782	1-249-435-11	CARBON	33K	5%	1/4W
R783	1-249-417-11	CARBON	1K	5%	1/4W
R784	1-249-429-11	CARBON	10K	5%	1/4W
R785	1-249-410-11	CARBON	270	5%	1/4W
R786	1-249-425-11	CARBON	4.7K	5%	1/4W
R787	△ 1-212-861-11	FUSIBLE	15	5%	1/4W F
R789	1-249-433-11	CARBON	22K	5%	1/4W
R791	1-247-838-00	CARBON	2K	5%	1/4W
R792	1-249-437-11	CARBON	47K	5%	1/4W
R793	1-249-429-11	CARBON	10K	5%	1/4W
R794	1-249-405-11	CARBON	100	5%	1/4W
R801	1-249-435-11	CARBON	33K	5%	1/4W
R802	1-249-435-11	CARBON	33K	5%	1/4W
R803	1-249-435-11	CARBON	33K	5%	1/4W
R805	1-249-437-11	CARBON	47K	5%	1/4W
R806	1-249-437-11	CARBON	47K	5%	1/4W
R807	1-249-441-11	CARBON	100K	5%	1/4W
R808	1-249-441-11	CARBON	100K	5%	1/4W
R809	1-249-437-11	CARBON	47K	5%	1/4W
R810	1-249-405-11	CARBON	100	5%	1/4W
R811	1-249-405-11	CARBON	100	5%	1/4W
R821	1-249-441-11	CARBON	100K	5%	1/4W
R851	1-215-457-00	METAL	33K	1%	1/6W
R852	1-247-893-11	CARBON	390K	5%	1/4W
R853	1-249-441-11	CARBON	100K	5%	1/4W
R854	1-247-895-00	CARBON	470K	5%	1/4W
R855	1-249-441-11	CARBON	100K	5%	1/4W

VARIABLE RESISTOR

RV701	1-230-497-11	RES, ADJ, CARBON 20K
RV702	1-230-498-11	RES, ADJ, CARBON 50K
RV703	1-228-991-00	RES, ADJ, METAL GLAZE 2.2K
RV704	1-230-497-11	RES, ADJ, CARBON 20K
RV705	1-230-497-11	RES, ADJ, CARBON 20K

CRYSTAL

X801	1-567-094-00	VIBRATOR, CERAMIC (3.58MHz)
XF701	1-567-908-11	VIBRATOR, CRYSTAL (16.9344MHz)

*1-629-995-11 CD MOTOR BOARD

CONNECTOR

CN713	*1-566-003-11	PIN, CONNECTOR (PC BOARD) 6P
-------	---------------	------------------------------

*1-638-104-11 GEQ VOL BOARD

CONNECTOR

CNP307	*1-566-970-11	HOUSING, CONNECTOR(PC BOARD)8P
--------	---------------	--------------------------------

VARIABLE RESISTOR

RV301	1-238-481-11	RES, VAR, SLIDE 50KX6 (GRAPHIC EQUALIZER/BALANCE)
-------	--------------	--

Note:

The components identified by mark △ or dotted line with mark △ are critical for safety. Replace only with part number specified.

Note:

Les composants identifiés par une marque △ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

POWER**TC**

Ref.No Part No. Description Remark

*1-629-992-11 POWER BOARD

CAPACITOR

C901	1-124-771-00	ELECT	6800MF	20%	25V
C902	1-161-379-00	CERAMIC	0.01MF	30%	25V
C903	1-161-494-00	CERAMIC	0.022MF	30%	25V
C904	1-161-379-00	CERAMIC	0.01MF	30%	25V
C905	1-161-379-00	CERAMIC	0.01MF	30%	25V

CONNECTOR

CN903 *1-506-988-11 PIN, CONNECTOR (PC BOARD) 6P

DIODE

D901 8-719-500-55 DIODE D3SBA10

JACK

J901 Δ 1-526-818-11 INLET, AC (~AC IN)

TRANSFORMER

T902 Δ 1-424-150-11 TRANSFORMER, LINE FILTER

*1-638-105-11 TC BOARD

CAPACITOR

C350 1-124-927-11 ELECT 4.7MF 20% 50V

CONNECTOR

CNP308 *1-566-779-11 PIN, CONNECTOR (PC BOARD) 4P
CNP310 *1-569-750-11 PIN, CONNECTOR (PC BOARD) 8P
CNP312 *1-560-456-00 PIN, CONNECTOR 2P

TRANSISTOR

Q314 1-807-868-11 TRANSISTOR KSR1006
Q315 1-807-868-11 TRANSISTOR KSR1006
Q316 8-729-119-78 TRANSISTOR 2SC2785-HFE
Q317 8-729-115-30 TRANSISTOR 2SK105A-30

RESISTOR

R333	1-249-417-11	CARBON	1K	5%	1/4W
R334	1-249-427-11	CARBON	6.8K	5%	1/4W
R335	1-249-429-11	CARBON	10K	5%	1/4W
R352	1-249-423-11	CARBON	3.3K	5%	1/4W

VARIABLE RESISTOR

RV303 1-241-037-21 RES, ADJ, CARBON 2.2K
RV304 1-241-037-21 RES, ADJ, CARBON 2.2K

Ref.No Part No. Description Remark

MISCELLANEOUS

1-452-531-11 MAGNET
 Δ 8-848-137-11 DEVICE, OPTICAL KSS-150B(J)
ANT1 1-501-383-21 ANTENNA, TELESCOPIC
F901 Δ 1-576-030-11 FUSE, GLASS TUBE (5A,125V)
HE301 1-543-525-11 HEAD, MAGNETIC (ERASE)
HP301 1-543-628-11 HEAD, MAGNETIC (REC/PB)
HRP301 1-543-628-11 HEAD, MAGNETIC (REC/PB)
M301 X-4920-924-1 MOTOR ASSY
M702 1-541-352-11 MOTOR, SPINDLE
M703 X-2641-357-1 MOTOR ASSY, SLED
S304 1-571-330-21 SWITCH, LEAF (MD (A) POWER)
S305 1-571-890-11 SWITCH, LEAF (REC PROOF)
S306 1-571-330-21 SWITCH, LEAF (MD (B) POWER)
S307 1-571-890-11 SWITCH, LEAF (120 μ /70 μ)
S801 1-570-822-21 SWITCH, LEAF (OPEN DET)
S802 1-571-936-11 SWITCH, LEAF (LIMIT IN)
T901 Δ 1-449-613-11 TRANSFORMER, POWER

ACCESSORIES & PACKING MATERIALS

Δ 1-557-287-11 CORD, POWER
*3-365-849-01 INDIVIDUAL CARTON....(US)
*3-365-849-11 INDIVIDUAL CARTON....(Canadian)
3-752-746-21 MANUAL, INSTRUCTION (ENGLISH)
3-752-746-31 MANUAL, INSTRUCTION (FRENCH)....(Canadian)
*4-934-506-01 CUSHION (UPPER LEFT)
*4-934-508-01 CUSHION (LOWER LEFT)

HARDWARE LIST

#1	7-685-104-19	SCREW +P 2X6 TYPE2 NON-SLIT
#2	7-685-132-19	SCREW +P 2.6X5 TYPE2 NON-SLIT
#3	7-685-648-79	SCREW, TAPPING +BV 3X12
#4	7-621-770-87	SCREW +B2.6X5
#5	7-685-133-19	SCREW +P 2.6X6 TYPE2 SLIT
#6	7-682-549-04	SCREW +B 3X10
#7	7-685-647-79	SCREW +BTP 3X10 TYPE2 N-S
#9	7-621-772-10	SCREW +B 2X4
#11	7-621-255-25	SCREW +BVTT 2X4 (S)
#12	7-621-255-15	SCREW +P 2X3
#13	7-621-255-45	SCREW +PTT 2X6 (S)
#15	7-685-144-19	SCREW +P 3X5 TYPE2 NON-SLIT
#16	7-682-548-04	SCREW +BVTT 3X8 (S)
#17	7-685-646-79	SCREW +BVTP 3X8 TYPE2 IT-3

Note:

The components identified by mark Δ or dotted line with mark Δ are critical for safety. Replace only with part number specified.

Note:

Les composants identifiés par une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

CFD-460

SONY[®] **SERVICE MANUAL**

US Model
Canadian Model

SUPPLEMENT-1

File this supplement with the service manual.

Subject : Change the CD main board


ELECTRICAL PARTS LIST

DIFFERENCE BETWEEN NEW AND FORMER TYPES

New Type						Former Type				
Ref.No.	Part No.	Description			Remark	Part No.	Description			Remark
		<CAPACITOR>					<CAPACITOR>			
C735	1-124-252-00	ELECT	0.33uF	20%	50V	1-162-284-31	CERAMIC	150PF	10%	50V
		<IC>					<IC>			
IC702	8-759-061-38	IC	KA8309			8-752-037-48	IC	CXA1182Q-Z		
IC703	8-759-061-39	IC	KS5990			8-752-328-46	IC	CXD1130Q		
IC704	DELETE					8-759-984-09	IC	LH5116NA-10		
		<RESISTOR>					<RESISTOR>			
R714	1-249-427-11	CARBON	6.8K	5%	1/4W	1-249-425-11	CARBON	4.7K	5%	1/4W
R716	1-247-883-00	CARBON	150K	5%	1/4W	1-247-886-11	CARBON	200K	5%	1/4W
R717	1-215-427-00	METAL	1.8K	1%	1/4W	1-249-422-11	CARBON	2.7K	5%	1/4W
R721	1-249-438-11	CARBON	56K	5%	1/4W	1-249-437-11	CARBON	47K	5%	1/4W
R724	1-249-439-11	CARBON	68K	5%	1/4W	1-249-438-11	CARBON	56K	5%	1/4W
R731	1-215-461-00	METAL	47K	1%	1/4W	1-215-457-00	METAL	33K	5%	1/4W
R732	1-215-461-00	METAL	47K	1%	1/4W	1-215-457-00	METAL	33K	5%	1/4W
R795	1-249-437-11	CARBON	47K	5%	1/4W					


DIAGRAMS

SCHEMATIC DIAGRAM —CD SECTION—



PRINTED WIRING BOARD —CD SECTION—

[CD MAIN BOARD]



04

